

# 15/25/35 kV 600/900A DEADBREAK INSULATED CAP INSTALLATION & OPERATING INSTRUCTIONS

#### **DESCRIPTION:**

The CHARDON 600/900A class deadbreak insulated cap fully meets the requirements of IEEE St. 386 standard. They are fully shielded, fully submersible and interchangeable with all other manufacturers that certify compliance of the following ANSI/IEEE St. 386 requirements: 15,25kV and 35 Class (8.3,15.2 and 21.1kV Phase-to-ground), 600 and 900A Class.

#### **KIT CONTENT:**

- Insulated Cap
- Silicone Lubricant
- Paper Towel
- Instruction Sheet



#### **CAUTION:**

- The installation of Chardon products must be carried out by qualified technical personnel.
- Contact with energized equipment can cause serious damage and even death.
- Wear appropriate protective equipment.
- Make sure Chardon Accessories are completely dry and in good condition at the time of installation.



#### **DANGER:**

- Do not touch or handle energized products without adequate protective equipment. Errors in the compliance of this instruction can result in damage to the product, serious injuries to people and even death.
- All associated equipment must be de-energized during installation and maintenance.
- The following instructions do not cover details or variables in the change / installation of the product, to prevent contingencies, please contact the team of Chardon technicians if required.

## **SAFETY INFORMATION**

The instructions in this manual are not intended as a substitute for proper training or adequate experience in the safe operation of the equipment described. Only competent technicians, who are familiar with this equipment should install, operate and service it.


# Warranty

Chardon products are guaranteed for a period of 2 years after their date of purchase, to make this guarantee effective you can come only by presenting a purchase invoice to your authorized Chardon distributor. The warranty will not be valid in the following cases:

- 1. When the product has been used under conditions other than normal.
- 2. When the product has not been operated according to the instructions for use.
- 3. When the product has been altered or repaired by persons not authorized by Chardon.
- 4. When using components that are no compatible with Chardon accessories.

Inasmuch as CHARDON GROUP, Inc. has no control over the use which others may put the material, it does not guarantee that the same results as those described herein will be obtained, each user of the material should make his own tests to determine the material's suitability for his own particular use. Statements concerning possible uses of the materials described herein are not to be construed as constituting a license under any CHARDON GROUP, inc. patent covering such use or as recommendations for use of such materials in the infringement of any patent.


FOR MORE INFORMATION, PLEASE CONTACT YOUR LOCAL DEALER





## NOTE:

Do not substitute other lubricants for those provided.



# STEP 1:

- **A.** Ensure the **Insulated Cap** has the same voltage rating as the equipment system.
- **B.** Ensure all cables and equipment are properly de-energized.

# STEP 2:

**C.** Clean the interfaces of the **Insulated Cap** and Equipment Bushing and lubricate them by using the Silicone Lubricant provided in the kit.

# STEP 3:

- **D.** Push Insulated Cap onto mating bushing interface.
- **E.** Turn Insulated Cap to make a threaded connection. Continue turning the Insulated Cap until tight.
- **F.** Connect **Grounding Wire** on Insulated Cap to the grounding system.